

WEBTEX Control Solutions

SCR88.xx Circuit Fault Conditions Explained


1: All Circuit in working order.
OFF: Analogue signal
OFF: High Signal
No Internal Pot




2: All Circuit in working order.
ON: Analogue signal (+- 50%)
ON: High Signal
No Internal Pot




3: Open Circuit Load v1.
ON / OFF: Analogue signal (0/+- 50%)
ON / OFF: High Signal
No Internal Pot



4: Open Circuit Load v2.
ON / OFF: Analogue signal (0/+- 50%)
ON / OFF: High Signal
No Internal Pot



5: Open Circuit Breaker v1.
ON / OFF: Analogue signal (0/+- 50%)
ON / OFF: High Signal
No Internal Pot



6: Open Circuit Breaker v2.
ON / OFF: Analogue signal (0/+- 50%)
ON / OFF: High Signal
No Internal Pot

